



Index No	Part No	Description	Qty	Index No	Part No	Description	Qty
1	2050500603	Housing	1	31	2050500053	Flat shoe	1
2	2050496183	Spring Pin	1	32	<u>2050500063</u>	Screw	1
3	2050499813	Air Inlet	1	33	2050500073	O-ring	1
4	2050499823	Safety Lever Assy.	1	34	2050500083	Spring pin	1
5	2050499833	Valve Stem	1	35	2050500093	Bushing	1
6	2050499843	Adjust Valve	1	36	2050500103	Finger pad	1
7	<u>2050485133</u>	O-Ring	1	37	2050500113	Guard	1
8	<u>2050499853</u>	Spring	1	39	2050500133	Screw	1
9	2050500423	Exhaust Deflector	1	40	<u>2050500143</u>	Key	1
10	<u>2050485153</u>	O-Ring	1	41	2050500153	Tension bar	1
11	<u>2050485863</u>	O-Ring	1	42	2050500163	Screw	1
12	<u>2050499873</u>	Spacer	1	43	2050500173	Pulley	1
13	<u>2050486823</u>	Ball bearing	1	45	2050500193	Screw	1
14	2050499883	Rear end plate	1	46	2050500203	Screw thread insert	1
15	2050499893	Rotor	1	47	2050500213	Guard body	1
16	<u>2050499903</u>	Blades (set of 4)	1	48	2050500223	Grip	1
17	2050499913	Screw	1	52	<u>2050485623</u>	O-ring	1
18	2050499923	Cylinder	1	53	2050500243	Screw	1
19	2050499933	Front end plate	1	54	2050500253	Pin	1
20	<u>2050486843</u>	Bal bearing	1	55	2050500263	Hex. Key Wrench (4mm)	1
21	2050499953	Cap	1	56	2050500273	Hex. Key Wrench (2.5mm)	1
22	2050499963	Drive pulley	1	2050468093	Warning label	1	
23	2050499973	Nut	1	2050468093	Warning label	1	
24	2050499983	Guard body luck	1				
25	2050499993	Screw	1		Tune-up kit	1	
26	2050500003	Dust cover	1		2050503863 (Incl. Part No: 7.8.10.11.12.13.16.20.33.40.52)		
27	2050500013	Spring	1				
28	2050500023	Pin	1				
29	2050500033	Screw	1				
30	2050500043	Washer	1				



8940168906	OPERATOR'S MANUAL
8940168305	EC DECLARATION
6159948770	SAFETY INSTRUCTIONS